

Replacement instructions

DSLX px Vx
by
VPM-VC


The replacement of the DSLX px Vx by a VPM-VC must be carried out by a qualified personnel only.

The function of the VPM-VC corresponds largely to the control devices DSLX px Vx. After the replacement, a function check must be carried out by a qualified and skilled person.


The conversion instruction does not replace the operating and mounting instructions of the VPM-VC and the DSLX px Vx. These instructions are absolutely necessary for the conversion and the further safe operation.



Work on the VPM may only be performed by specialist staff.




Any adjustment and application-specific adjustment values must be made in accordance with the appliance/boiler manufacturers instructions.



Never perform any work on the device when it is under voltage. Observe public regulations.



On completion of work on the VPM, perform a leakage and function test.



Do not allow any direct contact between the VPM and hardened masonry, concrete walls or floors.



If these instructions are not heeded, the result may be personal injury or damage to property.



The warranty for the device is void if the electrotechnical components are tampered with, i.e. automatically when the lead seal is damaged.

We reserve the right to make modifications in the course of technical development.

Head Offices and Factory	Postal address
Karl Dungs GmbH & Co. KG	Karl Dungs GmbH & Co. KG
Karl-Dungs-Platz 1	Postfach 12 29
D-73660 Urbach, Germany	D-73602 Schorndorf
Telefon +49 7181-804-0	e-mail info@dungs.com
Telefax +49 7181-804-166	Internet www.dungs.com



The Pressure Equipment Directive (PED) and the Energy Performance of Buildings Directive (EPBD) require a periodic inspection of **heating appliances** in order to ensure a high degree of efficiency over a long term and, consequently, the least environmental pollution. **It is necessary to replace safety-relevant components after they have reached the end of their useful life. This recommendation applies only to heating appliances and not to industrial heating processes. DUNGS recommends replacing such components according to the following table:**


Safety relevant component	DUNGS recommends replacement after:	Operating cycles
Valve proving systems	10 years	250.000
Pressure switch	10 years	N/A
Automatic burner control with flame safeguard	10 years	250.000
Flame detector (UV probes)	10.000 h Operating hours	
Gas pressure regulators	15 years	N/A
Gas valve with valve testing system	after error detection	
Gas valve without valve testing system*	10 years	250.000
Low gas pressure switch	10 years	N/A
Pressure relief valve	10 years	N/A
Gas-air ratio control system	10 years	N/A
* Gas families I, II, III		N/A not applicable

Content

Venting through roof: 2 pilot valves.....	4-5
Venting through roof: 1 pilot valve.....	6-7
Venting into the burner room: 2 pilot valves.....	8-9
Venting into the burner room: 1 pilot valve.....	10-11
Venting into the burner room: no pilot valve.....	12-13


DSL (old)

- DSL valve check with
- Pilot valves
 - Venting through roof



Never perform any work on the device when it is under voltage. Observe public regulations.

Electrical connection DSLC



DSL Connection

	of terminal	rewiring according to
PE	PE	
Pp / NO	1	
Pp / COM	2	
free	3	
Reset / IN	4	
Fault display 230 VAC	5	
Test request L1	6	
Reset / OUT	7	
free	8	
free	9	
LGV / 230 VAC	10	
Pp / NC	11	
free	12	
free	13	
V3 / 230 VAC	14	
Release / 230 VAC	15	
N	16	

only VPM-VC


New only VPM

Rewiring according DSLC → VPM-VC

VPM (new)

VPM valve check with

- **Pilot valves**
- **Venting through roof**




Never perform any work on the device when it is under voltage. Observe public regulations.

on terminal


VPM Connection

	on terminal	VPM Connection
→	PE	PE
→	13	Pp / NO
→		L1
→	12	Reset / IN (from L1)
→	17	Fault OUT 230 VAC
→	16	Fault IN (from L1)
→	4	Test request L1
→		L1
→	10	LGV / 230 VAC
→	14	Pp / NC
→	6	V3 / 230 VAC
→	11	Release / 230 VAC
→	3	N
	20	Multifunction output OUT 230 VAC
	19	Multifunction output 230 VAC
	18	free
	15	free
	9	free
	8	free
	7	free
	5	free
	2	L1 / time
	1	L1 / time

Electrical connection VPM-VC




DIP switch assignment




DSL (old)

- DSL valve check with
- Pilot valve
 - Venting through roof



Never perform any work on the device when it is under voltage. Observe public regulations.

Electrical connection DSL



DSL Connection	of terminal	rewiring according to
PE	PE	→
Pp / NO	1	→
Pp / COM	2	→
free	3	
Reset / IN	4	→
Fault display 230 VAC	5	→
		→
Test request L1	6	→
Reset / OUT	7	→
free	8	
free	9	
LGV / 230 VAC	10	→
Pp / NC	11	→
free	12	
Supply V1 / 230 VAC	13	→
V1 / 230 VAC	14	→
Release / 230 VAC	15	→
N	16	→


only VPM-VC

New only VPM

VPM (new)


VPM valve check with

- Pilot valve
- Venting through roof




Never perform any work on the device when it is under voltage. Observe public regulations.

Electrical connection VPM-VC




DIP switch assignment



on terminal	VPM Connection
PE	PE
13	Pp / NO
	L1
12	Reset / IN (von L1)
17	Fault OUT 230 VAC
16	Fault IN (from L1)
4	Test request L1
	L1
10	LGV / 230 VAC
14	Pp / NC
6	V1 / 230 VAC
11	Release / 230 VAC
3	N
20	Multifunction output OUT 230 VAC
19	Multifunction output IN 230 VAC
18	free
15	free
9	free
8	free
7	free
5	free
2	L1 / time
1	L1 / time


DSLCL (old)

- DSLCL valve check with
- Pilot valves
 - Venting into the burner room



Never perform any work on the device when it is under voltage. Observe public regulations.

Electrical connection DSLCL



DSLCL Connection

	of terminal	rewiring according to
PE	PE	
Pp / NO	1	
Pp / COM	2	
free	3	
Reset / IN	4	
Fault display 230 VAC	5	
Test request L1	6	
Reset / OUT	7	
free	8	
V4 / 230 VAC	9	
free	10	
Pp / NC	11	
free	12	
free	13	
V3 / 230 VAC	14	
Release / 230 VAC	15	
N	16	


only VPM-VC

New only VPM

VPM (new)

VPM valve check with

- Pilot valves
- Venting into the burner room




Never perform any work on the device when it is under voltage. Observe public regulations.




	on terminal	VPM Connection
→	PE	PE
→	13	Pp / NO
→		L1
→	12	Reset / IN (from L1)
→	17	Fault OUT 230 VAC
→	16	Fault IN 24 (from L1)
→	4	Test request L1
→		L1
→	8	V2 / 230 VAC
→	14	Pp / NC
→	6	V3 / 230 VAC
→	11	Release / 230 VAC
→	3	N
	20	Multifunction output OUT 230 VAC
	19	Multifunction output IN 230 VAC
	18	free
	15	free
	9	free
	8	free
	7	free
	5	free
	2	L1 / time
	1	L1 / time

Electrical connection VPM-VC




DIP switch assignment




DSLCL (old)

- DSLCL valve check with
- Pilot valve
 - Venting into the burner room



Never perform any work on the device when it is under voltage. Observe public regulations.

Electrical connection DSLCL



DSLCL Connection	of terminal	rewiring according to
PE	PE	
Pp / NO	1	
Pp / COM	2	
free	3	
Reset / IN	4	
Fault display 230 VAC	5	
Test request L1	6	
Reset / OUT	7	
free	8	
V4 / 230 VAC	9	
free	10	
Pp / NC	11	
free	12	
free	13	
V1 / 230 VAC	14	
Release / 230 VAC	15	
N	16	


only VPM-VC

New only VPM

VPM (new)


VPM valve check with

- Pilot valve
- Venting into the burner room




Never perform any work on the device when it is under voltage. Observe public regulations.

Electrical connection VPM-VC




DIP switch assignment



	on terminal	VPM Connection
→	PE	PE
→	13	Pp / NO
→		L1
→	12	Reset / IN (from L1)
→	17	Fault OUT 230 VAC
→	16	Fault IN (from L1)
→	4	Test request L1
→		L1
→	8	V4 / 230 VAC
→	14	Pp / NC
→	6	V1 / 230 VAC
→	11	Release / 230 VAC
→	3	N
	20	Multifunction output OUT 230 VAC
	19	Multifunction output IN 230 VAC
	18	free
	15	free
	9	free
	8	free
	7	free
	5	free
	2	L1 / time
	1	L1 / time


DSLCL (old)

- DSLCL valve check
- Venting into the burner room



Never perform any work on the device when it is under voltage. Observe public regulations.

Electrical connection DSLCL



DSLCL Connection	of terminal	rewiring according to
PE	PE	
Pp / NO	1	
Pp / COM	2	
free	3	
Reset / IN	4	
Fault display 230 VAC	5	
Test request L1	6	
Reset / OUT	7	
Versorgung V2 / 230 VAC	8	
V2 / 230 VAC	9	
free	10	
Pp / NC	11	
free	12	
Supply V1 / 230 VAC	13	
V1 / 230 VAC	14	
Release / 230 VAC	15	
N	16	


only VPM-VC

New only VPM


VPM (new)

DSLК valve check

- Venting into the burner room




Never perform any work on the device when it is under voltage. Observe public regulations.




	on terminal	VPM Connection
→	PE	PE
→	13	Pp / NO
→		L1
→	12	Reset / IN (from L1)
→	17	Fault OUT 230 VAC
	16	Fault IN 230 VAC
→	4	Test request L1
→		L1
→	9	Supply V2 / 230 VAC
→	8	V2 / 230 VAC
→	14	Pp / NC
→	7	Supply V1 / 230 VAC
→	6	V1 / 230 VAC
→	11	Release / 230 VAC
→	3	N
	20	Multifunction output OUT 230 VAC
	19	Multifunction output IN 230 VAC
	18	free
	15	free
	10	free
	5	free
	2	L1 / time
	1	L1 / time

Electrical connection VPM-VC



DIP switch assignment



Configuring test pressure switches Pp₁ and Pp₂


Instead of checking valve tightness with a test pressure switch Pp, two independent pressure switches can be used. This allows test pressure for V1 and V2 to be set individually.

Particularly with high input pressures and large test volumes, the total test time can be significantly reduced by using two pressure switches that can be set separately.

In contrast to only using one pressure switch Pp, for which both switch functions of the changeover contact are connected, when using two pressure monitors, only one contact (NO or NC) is connected at a time.

Test pressure switches for V1	Pp ₁	Opening (NC)
Test pressure switches for V2	Pp ₂	Closing (NO)
Pp ₁ checks the pressure rise	Tightness V1	Setting the pressure switch: Low pressure value
Pp ₂ checks the pressure drop	Tightness V2	Setting the pressure switch: High pressure value

Anschluss zwei Kontrolldruckwächter



We reserve the right to make modifications in the course of technical development.

Head Offices and Factory
Karl Dungs GmbH & Co. KG
Karl-Dungs-Platz 1
D-73660 Urbach, Germany
Telefon +49 7181-804-0
Telefax +49 7181-804-166

Postal address
Karl Dungs GmbH & Co. KG
Postfach 12 29
D-73602 Schorndorf
e-mail info@dungs.com
Internet www.dungs.com

We reserve the right to make modifications in the course of technical development.

Head Offices and Factory
Karl Dungs GmbH & Co. KG
Karl-Dungs-Platz 1
D-73660 Urbach, Germany
Telefon +49 7181-804-0
Telefax +49 7181-804-166

Postal address
Karl Dungs GmbH & Co. KG
Postfach 12 29
D-73602 Schorndorf
e-mail info@dungs.com
Internet www.dungs.com